




TrackLab S7 Installation Guide



Thank you for purchasing the TrackLab S7 4G GPS vehicle tracking device.

This Manual guide will help you with the device installation and utilization.

#1. Fleet Monitoring cloud platform

TrackLab provides a web-based Fleet Monitoring platform included with every device. Once you made the order, an account will be created for your fleet with all devices registered in one place.

Web platform: <https://mts.tracklab.tech/>

Login: [your email address in the invoice or that you provided to us.](#)

Contact us to support@tracklab.tech if you need help to find your account email login.

Password by default: [10203040@Aa](#)

You can change the password in the account Settings.

#2. Device activation

A device and a SIM card turn **Active** when you make an order and we assign it to your account. We ship the devices already with installed and activated SIM cards. You need to register a device in the Fleet account and link it to a vehicle you install. Please email us to support@tracklab.tech if you need help with the activation process and our Customer Success team will handle it.

All SIM cards are active for three (3) years since the activation moment. After that period of time TrackLab will extend the SIM life at the GSM provider.

If you need to change the installed SIM card, please reach out to support@tracklab.tech to get proper technical support through this process.

#3. Device installation

The device installation is quite simple, and usually takes about 30 minutes. We recommend connecting the device to a fuse box, ignition coil, or a fuel pump.

